

VL200 Instructions for use









VL200 20 PC





VL200 30 PC INOX






















2A








MANAN

l


4A










1B*)














1111


























Quick reference guide

The pictorial quick reference guide

The pictorial quick reference guide is designed for helping you when starting up, operating and storing the unit. The guide are subdivided into 3 sections, which are represented by symbols:

Α	× 🕄
Before starting	•
1A - Unpack Accessories	
2A - Filter Bag Installation	
3A - Hose Insert	
4A - Tube Fixed	
5A - Accessories Placement	ba
В	
Control/Operation	
1B - Emptying Container	
2B - Blow Function	
3B - Push&Clean	
4B - Cable Storage	
5B - Hose Storage	
C C	
Replacement of:	
1C - Filter Bag Replacement	
2C - Filter Replacement	

*) Optional accessories / Option depending on model

Contents

н

1	lmpo	rtant safety instructions 2
	1.1	Symbols used to mark instructions
	1.2	Instructions for use2
	1.3	Purpose and intended use2
	1.4	Electrical connection2
	1.5	Extension lead
	1.6	Guarantee
	1.7	Tests and approvals2
	1.8	Important warnings 3
	1.9	Double-insulated appliances*
	1.9.1	Only applicable to UK
	1.9.2	Electrical connections
	1.9.3	Blue-neutral brown-live4
•		
2	Risks	
	2.1	Electrical components
	2.2	Picking up liquids4
	2.3	Hazardous materials
	2.4	Spare parts and accessories
	2.5	Emptying dirt tank 4
	2.6	In explosive or inflammable atmosphere 5
	2.7	Blower function5
3	Cont	rol / Operation 5
	3.1	Starting and operating of the machine 5
	3.2	Before wet pick-up5
	3.3	Emptying after wet pick-up5
	3.4	Emptying after dry pick-up5
	3.5	Push&Clean5
4	After	using the cleaner 5
	4.1	After use
	4.2	Transport5
	4.3	Storage
	4.4	Recycling the cleaner
	4.4	
5		,
5	Main	tenance 6
5		,
-	Main 5.1 5.2	tenance6Regular servicing and inspection6Maintenance6
5	Maint 5.1 5.2 Furth	tenance6Regular servicing and inspection6Maintenance6Mer information7
-	Main 5.1 5.2	tenance6Regular servicing and inspection6Maintenance6

1 Important safety instructions

This document contains the safety information relevant for the appliance along with a quick reference guide. Before starting up your vacuum cleaner for the first time, this instruction manual must be read through carefully. Save the instructions for later use.

Further support

Further information on the appliance can be found on our web site at www.nilfisk.com. For further queries, please contact the Nilfisk ser-

For further queries, please contact the Nilfisk service representative responsible for your country. See reverse of this document.

1.1 Symbols used to mark instructions DANGER

 \triangle

Danger that leads directly to serious or irreversible injuries, or even death.

WARNING

Danger that can lead to serious injuries or even death.

CAUTION

Danger that can lead to minor injuries and damage.

1.2 Instructions for use

The appliance must:

- only be used by persons, who have been instructed in its correct usage and explicitly commissioned with the task of operating it
- only be operated under supervision
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
- Children shall be supervised to make sure that they do not play with the appliance.
- Do not use any unsafe work techniques.
- Never use the vacuum cleaner without a filter.
- Switch off the appliance and disconnect the mains plug in the following situations:
- Prior to cleaning and servicing
- Prior to replacing components
- Prior to changing over the appliance
- If foam develops or liquid emerges

Besides the operating instructions and the binding accident prevention regulations valid in the country of use, observe recognised regulations for safety and proper use.

1.3 Purpose and intended use

This vacuum cleaner is designed, developed and rigorously tested to function efficiently and safely when properly maintained and used in accordance with the following instructions.

This vacuum cleaner is to be used for commercial or for household use. Accidents due to misuse can only be prevented by those using the machine. READ AND FOLLOW ALL SAFETY INSTRUC-TIONS.

This machine is suitable for picking up dry, non-flammable dust and liquids.

Any other use is considered as improper use. The manufacturer accepts no liability for any damage resulting from such use. The risk for such use is borne solely by the user. Proper use also includes proper operation, servicing and repairs as specified by the manufacturer.

1.4 Electrical connection

- 1. It is recommended that the vacuum cleaner should be connected via a residual current circuit breaker.
- 2. Arrange the electrical parts (sockets, plugs and couplings) and lay down the extension lead so that the protection class is maintained.
- 3. Connectors and couplings of power supply cords and extension leads must be watertight.

1.5 Extension lead

- 1. As an extension lead, only use the version specified by the manufacturer or one of a higher quality.
- 2. When using an extension lead, check the minimum cross-sections of the cable:

Cable lenth	Cross section	
	< 16 A	< 25 A
up to 20 m	1.5 mm ²	2.5 mm ²
20 to 50 m	2.5 mm ²	4.0 mm ²

1.6 Guarantee

Our general conditions of business are applicable with regard to the guarantee.

Unauthorised modifications to the appliance, the use of incorrect brushes in addition to using the appliance in a way other than for the intended purpose exempt the manufacturer from any liability for the resulting damage.

1.7 Tests and approvals

Electrical tests must be performed in accordance with the provisions of safety regulations EN 62638. These tests must be performed at regular intervals and after repairs or modifications.

The vacuum cleaner has been approved in accordance with IEC/EN 60335-2-69.

WARNING

- To reduce the risk of fire, electric shock, or injury, please read and follow all safety instructions and caution mar-kings before use. This vacuum cleaner is designed to be safe when used for cleaning functions as specified. Should damage occur to electrical or mechanical parts, the cleaner and / or accessory should be repaired by a competent service station or the manufacturer before use in order to avoid further damage to the machine or physical injury to the user.
 - Do not leave the machine when it is plugged in. Unplug from the socket when not in use and before maintenance.
 - Do not use with damaged cord or plug. To unplug grasp the plug, not the cord. Do not handle plug or cleaner with wet hands. Turn off all controls before unplugging.
 - Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run cleaner over cord. Keep cord away from heated surfaces.
 - Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts. Do not put any objects into openings or use with opening blocked.
 Keep openings free of dust, lint, hair, and anything else that could reduce the flow of air.
 - This machine is not suitable for picking up hazardous dust.
 - Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
 - Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
 - Use extra care when cleaning on stairs.
 - Do not use unless filters are fitted.
 - If the cleaner is not working properly or has been dropped, damaged, left out-doors, or dropped into water, return it to a service center or dealer.
 - If foam or liquid escapes from the machine, switch off immediately.
 - The vacuum cleaner may not be used as a water pump. The vacuum cleaner is intended for vacuuming air and water mixtures.
 - Connect the vacuum cleaner to a properly earthed mains supply. The socket outlet and the extension cable must have an operative protective conductor.
 - Provide for good ventilation at the working place.

 Do not use the vacuum cleaner as a ladder or step ladder. The vacuum cleaner can tip over and become damaged. Danger of injury.

1.9 Double-insulated appliances*

CAUTION



- Use only as described in this manual and only with the manufacturer's recommended attachments.
- BEFORE YOU PLUG IN YOUR CLEAN-ER, check the rating plate at the cleaner to see if the rated voltage agrees within 10% of the voltage available.
- This appliance is provided with double insulation. Use only identical replacement parts. See instructions for servicing double insulated appliances.

In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a mean for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated appliance must be identical to the parts they replace. A double insulated appliance is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED." The symbol (square within a square) may also be used on the product.

The machine is equipped with a specially designed cord which if damaged, must be replaced by a cord of the same type. This is available at authorised service centres and dealers and must be installed by trained personnel.

1.9.1 Only applicable to UK.

Please read these essential instructions

These instructions have been prepared with safety and efficiency paramount.

The machine operator must be trained by a suitably qualified instructor and must understand these instructions for use, and be made aware of any relevant regulations and legislation in force at the time of use.

1.9.2 Electrical connections

CAUTION

DOUBLE-INSULATED MACHINES -

This 240 volt 50 Hz. machine are fitted with a 13 amp. 3 pin moulded plug. The plug is fitted with a 13 amp. detachable fuse. The correct replacement for the fuse is identified by marking or colour coding. Only fuses that are ASTA approved to BS 1362 should be fitted.



Never use the plug without the fuse cover fitted. Replacement fuse covers are available at any electrical retail outlet.

If the available socket outlet is not suitable for the plug supplied, the plug must be cut off and an appropriate plug fitted. The plug thus cut off MUST BE DESTROYED for safety reasons before being disposed of.

Machines built for other voltages and frequencies are not normally supplied with a fitted plug.

If it is necessary to fit a plug, the wires in this power supply cord are coloured in accordance with the following code:

1.9.3 Blue-neutral brown-live

TO CONNECT THE NEW PLUG If using a three-pin plug, do not make any connection to the the terminal in the plug which is marked with the letter 'E' or by the safety earth symbol or coloured green or green & yellow.

The blue wire must be connected to the terminal in the plug which is marked with the letter 'N' or is coloured black or blue.

BL

The brown wire which must be connected to the terminal in the plug which is marked with the letter 'L' or is coloured red or brown.

If the plug to be fitted does not conform to the above notation then consult a qualified electrician.

2 Risks

2.1 **Electrical components**

DANGER

The upper section of the vacuum cleaner contains live components.

Contact with live components leads to serious or even fatal injuries.

Never spray water on to the upper section of the vacuum cleaner.

DANGER

Electric shock due to faulty mains connecting lead.

Touching a faulty mains connecting lead can result in serious or even fatal injuries.

- Do not damage the mains power lead (e.g. by driving over it, pulling or crushing it).
- Regularly check whether the power cord is damaged or shows signs of ageing.
- If the electric cable is damaged, it must be replaced by an authorized Nilfisk distributor or similar qualified person in order to avoid a hazard.
- In no circumstances should the power .

supply cord be wrapped around fingers or any part of the operators person.

CAUTION

Damage due to unsuitable mains voltage.

The appliance can be damaged as a result of being connected to an unsuitable mains voltage.

Ensure that the voltage shown on the rating plate corresponds to the voltage of the local mains power supply.

Picking up liquids

CAUTION

Picking up liquids.

2.2

FUSE

CORD CLAMP

Do not pick up flammable liquids

- Before liquids are picked up, always remove the filter bag/wastebag and check that the float or the water level limit works properly.
- The use of a separate filter element or filter screen is recommended.
- If foam appears, stop work immediately and emty the tank.

2.3 **Hazardous materials**

WARNING

Hazardous materials.

Vacuuming up hazardous materials can lead to serious or even fatal injuries

- The following materials must not be picked up by the vacuum cleaner:
- hazardous dust
- hot materials (burning cigarettes, hot ash, etc.)
- flammable, explosive, aggressive liquids (e.g. petrol, solvents, acids, alkalis, etc.)
- flammable, explosive dust (e.g. magnesium or aluminium dust, etc.)

2.4 Spare parts and accessories CAUTION



Spare parts and accessories.

The use of non-genuine spare parts and accessories can impair the safety of the appliance.

- Only use spare parts and accessories from Nilfisk.
- Use only the brushes supplied with the vacuum cleaner or specified in the operating manual.

2.5 **Emptying dirt tank**

CAUTION



Picking up environmentally hazardous materials.

Materials picked up can present a hazard to the environment.

- Dispose of the dirt in accordance with legal regulations.
- 2.6 In explosive or inflammable atmosphere CAUTION

This machine is not suitable for use in explosive or inflammable atmospheres or where such atmospheres are likely to be produced by the presence of volatile liquid or inflammable gas or vapour.

2.7 Blower function.

CAUTION

The vacuum cleaner has a blower function. Do not blow the outgoing air randomly in enclosed areas. Use the blower function only with a clean hose. Dusts can be hazardous to one's health.

3 Control / Operation

3.1 Starting and operating of the machine

Check that the electrical switch is switched off (in position 0). Check that suitable filters are installed in the machine. Then connect the suction hose into the suction inlet at the machine by pushing the hose forward until it fits firmly in place at the inlet. Then connect the two tubes with the hose handle, twist the tubes in order to ensure that they are properly fitted. Attach suitable nozzle to the tube. Choose nozzle depending on what type of material that is to be picked-up. Connect the plug into a proper electrical outlet. Put the electrical switch into position 1 in order to start the motor.



Press I : Activate the machine Press 0 : Stop the machine

3.2 Before wet pick-up

CAUTION

The machine is equipped with a float system that shuts off the airflow through the machine when the maximum liquid level is reached. You will hear a noticeable change of the sound from the motor and notice that the suction power decreases. When this occurs, switch the machine off. Disconnect the machine from the socket. Never pick up liquid without the float body in place.

3.3 Emptying after wet pick-up

Before emptying the container, unplug the vacuum cleaner. Disconnect the hose from the inlet by pulling out the hose. Release the latch by pulling them outwards so that the motor top is released. Open up the motor top from container. Always empty and clean the container and the float system after picking-up

^{*)}Optional accessories / Option depending on model Original instruction liquids. Never pick up liquid without the float system and filter installed in the machine.

Empty by tilting the container backwards and pour the liquids into a floor drain or similar.

Put back the motor top to the container. Secure the motor top with the latches.

3.4 Emptying after dry pick-up

Remove the electrical plug from the socket before emptying after dry pick-up. Check the filters and dustbag regularly. Release the latch by pulling them outwards so that the motor top is released. Open up the motor top from container.

Cartridge filter: To clean the filter you can either shake, brush or wash it. Wait until it is dry before you reuse it.

Dustbag: check bag to ensure the fill factor. Replace dust bag if necessary. Remove the old bag. The new bag is fitted by passing the carboard piece with the rubber membrane through the vacuum inlet. Make sure that the rubber membrane is passing past the heightening at the vacuum inlet.

After emptying: Close motor top to the container and secure the motor top with the latches. Never pick up dry material without cartridge filter and dustbag fitted in the machine. The suction efficiency of the vacuum cleaner depends on the size and quality of the filter and dust bag. Therefore - use only Original filter and dust bags.

3.5 Push&Clean

The machine is equipped with a semi automatic filter cleaning system. Push&Clean. The filter cleaning system must be actuated latest when the vacuuming performance is no longer sufficient. Regular use of the filter cleaning feature increases the tool life of the filter.

4 After using the cleaner

4.1 After use

Remove the plug from the socket when machine is not in use. Wind up the cord starting from the machine. The power cord can be wound up around the motor top or at the container. Some variants have special storage places for accessories.

4.2 Transport

- Before transporting the dirt tank, close all the locks.
- Do not tilt the cleaner if there is liquid in the dirt tank.
- Do not use a crane hook to lift the cleaner.

EN

4.3 Storage

- Store the appliance in a dry place, protected from rain and frost.
- The machine shall be stored indoors only.

4.4 Recycling the cleaner

Make the old cleaner unusable.

- 1. Unplug the cleaner.
- 2. Cut the power cord.
- 3. Do not discard of electrical appliances with household waste.
 - As specified in European Directive 2012/19/EC
 - on old electrical and electronic appliances,
 - used electrical goods must be collected separately and recycled ecologically.

5 Maintenance

5.1 Regular servicing and inspection

Regular servicing and inspection of your machine must be carried out by suitably qualified personnel in accordance with relevant legislation and regulations. In particular, electrical tests for earth continuity, insulation resistance, and condition of the flexible cord should be checked frequently.

In the event of any defect, the machine MUST be withdrawn from service, completely checked and repaired by an authorized service technician.

5.2 Maintenance

Remove the plug from the socket before performing maintenance. Before using the machine make sure that the frequency and voltage shown on the rating plate correspond with the mains voltage.

The cleaner is designed for continuous heavy work. Depending on the number of running hours – the dust filter should be renewed. Keep the vacuum cleaner clean with a dry cloth, and a small amount of spray polish.

For details of after sales service contact your dealer or Nilfisk service representative responsible for your country. See reverse of this document.

6 Further information

6.1 EU Declaration of conformity

(€	Declaration of Conformity
Product:	Vacuum cleaner for wet and dry operation
Туре:	VL200 ** PC **
The design of the unit corresponds to	EC - Machinery Directive 2006/42/EC
the following pertinent regulations:	EC - Directive EMC 2004/108/EC
	EC - RoHS Directive 2011/65/EC
Applied harmonised standards:	EN 60335-1:2012,
	EN 60335-2-69:2012,
	EN 55014-1:2006+A1:2009+A2:2011,
	EN 55014-2:1997+A1:2001+A2:2008,
	EN 61000-3-2:2006+A1:2009+A2:2009,
	EN 61000-3-3:2008
Name and address of the person	Anton Sørensen, Senior Vice President, Global R&D
authorised to compile the technical	Nilfisk A/S
file:	Kornmarksvej 1
	DK-2605 Broendby
Identity and signature of the person empowered to draw up the declara- tion on behalf of the manufacturer.	Appliers-
tion on benair of the manufacturer.	Anton Sørensen, Senior Vice President, Global R&D
	Nilfisk A/S
	Kornmarksvej 1
	DK-2605 Broendby
Place and date of the declaration:	Hadsund 2015-12-21

6.2 Specifications

		VL 200 20 PC	VL 200 30 PC INOX
Possible voltage	V	220-240	220-240
Power P _{iec}	W	1200	1200
Mains frequency	Hz	50-60	50-60
Protection grade (moist, dust)		IP24	IP24
Protection class (electrical)		II 🗆	11 🗆
Airflow	l/min m3/h	48	48
Vacuum	kPa	230	230
Sound pressure level 1 m, EN 60704-1	dB(A)+/-2	72	72
Working sound level	dB(A)+/-2	64	64
Vibration ISO 5349	m/s²+/- 1	<1,5	<1,5
Tank capacity	litres	20	30
Weight	kg	7,5	10,5

Specifications and details are subject to change without prior notice.



HEAD QUARTER

DENMARK Nilfisk A/S Kornmarksvej 1 DK-2605 Broendby Tel.: (+45) 4323 8100 www.nilfisk.com

SALES COMPANIES

ARGENTINA Nilfisk srl. Edificio Central Park Herrera 1855, 6th floor/604 Ciudad de Buenos Aires Tel.: (+54) 11 6091 1571 www.nilfisk.com.ar

AUSTRALIA

Nilfisk Pty Ltd Unit 1/13 Bessemer Street Blacktown NSW 2148 Tel.: (+61) 2 98348100 www.nilfisk.com.au

AUSTRIA

Nilfisk GmbH Metzgerstrasse 68 5101 Bergheim bei Salzburg Tel.: (+43) 662 456 400 90 www.nilfisk.at

BELGIUM

Nilfisk n.v-s.a. Riverside Business Park Boulevard Internationalelaan 55 Bâtiment C3/C4 Gebouw Bruxelles 1070 Tel.: (+32) 24 67 60 50 www.nilfisk.be

BRAZIL

Nilfisk do Brasil Nilfisk do Brasil Av. Eng. Luis Carlos Berrini, 550 40 Andar, Sala 03 SP - 04571-000 Sao Paulo Tel.: (+11) 3959-0300 / 3945-4744 www.nilfisk.com.br

CANADA

Nilfisk Canada Company 240 Superior Boulevard Mississauga, Ontario L5T 2L2 Tel.: (+1) 800-668-8400 www.nilfisk.ca

CHILE

Nilfisk S.A. (Comercial KCS Ltda) Salar de Llamara 822 8320000 Santiago Tel.: (+56) 2684 5000 www.nilfisk.cl

CHINA

Nilfisk 4189 Yindu Road Xinzhuang Industrial Park 201108 Shanghai Tel.: (+86) 21 3323 2000 www.nilfisk.cn

CZECH REPUBLIC

Nilfisk s.r.o. VGP Park Horní Počernice Do Čertous 1/2658 193 00 Praha 9 Tel.: (+420) 244 090 912 www.nilfisk.cz

DENMARK

Nilfisk Danmark A/S Industrivej 1 Hadsund, DK-9560 Tel.: 72 18 21 20 www.nilfisk.dk

FINLAND

Nilfisk Oy Ab Koskelontie 23 E 02920 Espoo Tel.: (+358) 207 890 600 www.nilfisk.fi

FRANCE

Nilfisk SAS 26 Avenue de la Baltique Villebon sur Yvette 91978 Courtabouef Cedex Tel.: (+33) 169 59 87 00 www.nilfisk.fr

GERMANY Nilfisk GmbH

Guido-Oberdorfer-Straße 2-10 89287 Bellenberg Tel.: (+49) (0)7306/72-444 www.nilfisk.de

GREECE Nilfisk A F

Αναπαύσεως 29 Κορωπί Τ.Κ. 194 00 Tel.: (30) 210 9119 600 www.nilfisk.gr

HOLLAND Nilfisk B V Versterkerstraat 5

1322 AN Almere Tel.: (+31) 036 5460760 www.nilfisk.nl HONG KONG

Nilfisk Ltd. 2001 HK Worsted Mills Industrial Building 31-39, Wo Tong Tsui St. Kwai Chung, N.T. Tel.: (+852) 2427 5951 www.nilfisk.com

HUNGARY

Nilfisk Kft. II. Rákóczi Ferenc út 10 Tel.: (+36) 24 475 550 www.nilfisk.hu

INDIA

Nilfisk India Limited Pramukh Plaza, 'B' Wing, 4th floor, Unit No. 403 Cardinal Gracious Road, Chakala Andheri (East) Mumbai 400 099 Tel.: (+91) 22 6118 8188 www.nilfisk.in

IRELAND

Nilfisk 1 Stokes Place St. Stephen's Green Dublin 2 Tel.: (+35) 3 12 94 38 38 www.nilfisk.ie

ITALY

Nilfisk SpA Strada Comunale della Braglia, 18 26862 Guardamiglio (LO) Tel.: (+39) (0) 377 414021 www.nilfisk.it

JAPAN Nilfisk Inc. 1-6-6 Kita-shinyokohama, Kouhoku-ku
Yokohama, 223-0059
Tel.: (+81) 45548 2571 www.nilfisk.com

MALAYSIA

Nilfisk Sdn Bhd Sd 33, Jalan KIP 10 Taman Perindustrian KIP Sri Damansara 52200 Kuala Lumpur Tel.: (60) 3603 627 43 120 www.nilfisk.com

MEXICO

Nilfisk de Mexico, S. de R.L. de C.V. Pirineos #515 Int. 60-70 Microparque Industrial WSantiago 76120 Queretaro Tel.: (+52) (442) 427 77 00 www.nilfisk.com

NEW ZEALAND

Nilfisk Limited Suite F, Building E 42 Tawa Drive 0632 Albany Auckland Tel.: (+64) 9 414 1996 Website: www.nilfisk.com

NORWAY Nilfisk AS

Bjørnerudveien 24 1266 Oslo Tel.: (+47) 22 75 17 80 www.nilfisk.no

PERU Nilfisk S.A.C. Calle Boulevard 162, Of. 703, Lima 33-Perú Lima Tel.: (511) 435-6840 www.nilfisk.com

POLAND Nilfisk Sp. Z.O.O. Millenium Logistic Park ul. 3 Maja 8, Bud. B4 05-800 Pruszków Tel.: (+48) 22 738 3750 www.nilfisk.pl

PORTUGAL

Nilfisk Lda. Sintra Business Park Zona Industrial Da Abrunheira Edificio 1, 1° A P2710-089 Sintra Tel.: (+351) 21 911 2670 www.nilfisk.pt

RUSSIA

Nilfisk LLC Vyatskaya str. 27, bld. 7/1st 127015 Moscow Tel.: (+7) 495 783 9602 www.nilfisk.ru

SINGAPORE

Den-Sin 22 Tuas Avenue 2 639453 Singapore Tel.: (+65) 6268 1006 www.densin.com

SLOVAKIA Nilfisk s.r.o

Bancíkovej 1/A SK-821 03 Bratislava Tel.: (+421) 910 222 928 www.nilfisk.sk

SOUTH AFRICA

Nilfisk (Pty) Ltd Kimbult Office Park 9 Zeiss Road Laser Park Honeydew Johannesburg Tel: +27118014600 www.nilfisk.co.za

SOUTH KOREA

Nilfisk Korea 3F Duksoo B/D, 317-15 Sungsoo-Dong 2Ga Sungdong-Gu, Seoul Tel.: (+82) 2497 8636 www.nilfisk.co.kr

SPAIN

Nilfisk S.A Torre d'Ara, Passeig del Rengle, 5 Plta. 10ª 08302 Mataró Tel.: (34) 93 741 2400 www.nilfisk.es

SWEDEN

Nilfisk AB Taljegårdsgatan 4 431 53 Mölndal Tel.: (+46) 31 706 73 00 www.nilfisk.se

SWITZERLAND

Nilfisk AG Ringstrasse 19 Kircheberg/Industri Stelz 9500 Wil Tel.: (+41) 71 92 38 444 www.nilfisk.ch

TAIWAN

Nilfisk Ltd Taiwan Branch (H.K) No. 5, Wan Fang Road Taipei Tel.: (+88) 6227 00 22 68 www.nilfisk.tw

THAILAND

Nilfisk Co. Ltd. Nillisk Co. Ltd. 89 Soi Chokechai-Ruammitr Viphavadee-Rangsit Road Ladyao, Jatuchak, Bangkok 10900 Tel.: (+66) 2275 5630 www.nilfisk.co.th

TURKEY Nilfisk A.S

Serifali Mh. Bayraktar Bulv. Sehit Sk. No:7 Umraniye, 34775 Istanbul Tel.: +90 216 466 94 94 www.nilfisk.com.tr

UNITED ARAB EMIRATES Nilfisk Middle East Branch

SAIF-Zone P.O. Box 122298 Sharjah Tel.: (+971) (0) 655-78813 www.nilfisk.com

UNITED KINGDOM

Nilfisk Ltd. Nilfisk House, Bowerbank Way Gilwilly Industrial Estate, Penrith Cumbria CA11 9BQ Tel: (+44) (0) 1768 868995 www.nilfisk.co.uk

UNITED STATES

Nilfisk, Inc. 9435 Winnetka Ave N, Brooklyn Park MN- 55445 www.nilfisk.com

VIETNAM Nilfisk Vietnam No. 51 Doc Ngu Str. P. Vinh Phúc, Q.Ba Dinh Hanoi Tel.: (+84) 761 5642 www.nilfisk.com

